

REAR

FRONT

CW
Key
pass
through

CW
Key
pass
through

1/4
Mic
Input

Heil
Mic

Mic
and
PTT
output

1/4"
Heil
Hand
Switch

Hand
Switch

Foot
Switch

Heil
Phones

Radio
Spkr In

Radio
Spkr
Out

PC
Spkr In

PC
Spkr
Out



